

# Palm Bluetooth Intelligent Car Software Manual

## 蓝牙掌上智能车软件使用说明书

### 软件概述 Software Overview

This APP provides several control modes of remote control car, including "manual control", "gravity sensor", etc. User can choose a mode as he likes, to have an experience as driving a real car.

本APP提供了对遥控车多种不同的控制模式,包括“手动控制”、“重力感应”等模式。用户可以选择喜欢的模式对遥控车进行随心所欲的操作,完美地体验真车的快感。

### 使用前准备 Preparation

#### APP程序的安装 APP Installation

Please install the software we provide. An icon prompt emerges upon the completion of installation, as shown below.

首先安装我们提供的软件,安装完成可以看到如图所示图标。



#### 连接蓝牙 Bluetooth connection



Turn on Bluetooth, Click on the upper left corner the Bluetooth connection button to enter the Bluetooth connection interface, Bluetooth connection "CarCarClubBLEO".

打开蓝牙,启动软件,点击左上角蓝牙连接按钮进入连接蓝牙界面,选择蓝牙 "CarCarClubBLEO" 并点击连接。

### 详细使用 Usage



After the preparations are completed, you can play the car. First we can see mode selection interface; click a mode icon to select a mode. Click the set button at the top left corner to enter the setting interface, where you can set sound, select language, and view help.

经过上一步的准备工作,我们就可以来玩控爱车了。首先我们可以看到模式选择界面,点击模式图标可以进入相应的模式。点击左上角设置按钮进入设置界面,可以设置声音开关,选择语言,查看帮助。

#### 一、俱乐部 Club



Drag the direction arrow to the position to be subject to direction change, and click the play button to let the car drive to the parking space to get through the pass.

拖动方向箭头到需要改变方向的地方,点击播放按钮,让小车顺利驾驶到停车位,即闯关成功。

#### 二、保养中心 Maintenance Center



After entering the maintenance center, you can see six icons at the top of the interface, namely waster spray, foam, polish, respray, wipe, repolish. Drag the icons in order to maintain your car.

进入保养中心后,将看到界面上方有六个图标,依次为喷水、喷泡沫、抛光、再喷水、毛巾擦、再抛光。按顺序拖动图标对准小车进行保养,使小车变得崭新明亮。

#### 三、车库 Gar store



Click the yellow buttons on the left and right to select a car. Click the three blue buttons at the bottom left corner to select the color, wheel, and logo.

点击左右黄色按钮,选择喜欢的车。左下角三个蓝色按钮分别用于选择小车的颜色、车轮、徽标。

#### 四、驾驶室 Cab

##### 1. 控制 Control

Replace button steering wheel position and retreat position  
左右替换方向盘与进退按钮的位置



The manual control interface is simple and beautiful. There is a steering wheel, forward and back buttons, and a return icon. Press the forward or button buttons to make the car advance or retreat, move the steering wheel to control direction, and click the return icon at the top left corner to return to the mode selection interface.

手动控制界面简洁美观,有一个方向盘,前进后退按钮和一个返回图标。通过按住前进、后退按钮可以控制遥控车前进、后退,移动方向盘控制遥控车的方向。点击左上角返回图标可以返回至模式选择界面。

##### 2. 重力感应 Gravity Sensor



There is a forward and back buttons. Press the forward or button buttons to make the car advance or retreat. Pitching the phone towards the left to turn left, and towards the right to turn right, when a corresponding direction arrow is displayed in the center of the interface.

此界面有一个前进、一个后退按钮,按下按钮控制车的前进与后退。当手机拿在手中向左倾斜,遥控车将向左转向,当手机拿在手中向右倾斜,遥控车将向右转向,同时界面中央显示对应的方向箭头。