

Note :
Please ensure a safe flight and prevent interference from other wireless sources.

Learn About WIFI VER.

No controller is required for FLYING TANK. You can control the drone through smart phone or iPad via WiFi to perform functions, such as flying, and shooting photos or recording videos. All you need is to download the JJRC FLYING TANK.

How To Connect To WIFI

1.Download And Install JJRC FLYING TANK

iOS user please scan QR code in Figure 1 to download.
Android Mainland China user please scan QR code in Figure 2 to download.
Android oversea user please scan QR code in Figure 3 to download.



Figure 1



Figure 2




Figure 3




JJRC FLYING TANK

2.Connect To WIFI

Switch on the drone and the lights will flash. Go to Phone Settings and select JJRC WIFI, as shown in figure.



EXCELSIOR WiFi VER.
Quickstart Guide




How To Control With APP

1.APP Interface Description

- ①Turn on JJRC APP to enter the main interface, as shown in figure.
- ②Click “CONNECT →” to enter manipulation interface, as shown in figure.



- ③Click “⚙️” to enter the settings, as bellowed.



- ④Click “⏸️” to enter Altitude Hold mode interface. The icon will turn yellow, as shown in figure.

