



2.4G水陆遥控攀爬车使用说明

1. 认识你的遥控器




2. 遥控器安装电池及对频



遥控器使用2x1.5V "AA" 电池
(电池不包含)

遥控器对频说明：
打开遥控器电源开关，此时指示灯闪烁，打开遥控车电源开关，遥控器指示灯熄灭，遥控车与遥控器对频完成。


3. 遥控车电池安装说明




USB充电使用事项

1. 电池组第一次使用必须先充好电，以确保电量充足，如长期不使用则会自动放电，如充电过度则会缩短电池寿命。
2. 使用者应定期检查电线、插头、外壳及相关部件，若发生损坏必须停止使用，直至修复完好。
3. 玩具不能连接到不受推荐使用的电源上，充电条件：将USB智能充电线接上原厂电池。
4. 建议使用合适的适配器进行充电，不能使用快速充电器进行充电。
5. 请使用正确适配器进行充电，输入：100-240V~50/60Hz 0.2A；输出：5.0V 500mA 0.5-1.5A。
6. 充电说明：充电电池接上智能USB充电线，智能USB充电线可通过接入带有USB插口的电源介质，对电池进行充电，如：台式电脑、笔记本电脑、移动电源、USB电源插座或通过USB转接插头接入电源充电。
7. 长时间不使用遥控车，请将遥控车电池与遥控器电池取出。


4. 使用遥控器行驶




1. 前进
按下遥控器前进按键，遥控车前进。



2. 后退
按下遥控器后退按键，遥控车后退。



3. 左转
同时按下遥控器前进、左转按键，遥控车向左转。





4. 右转
同时按下遥控器前进、右转按键，遥控车向右转。

*请在操作前仔细阅读说明书并妥善保管以便日后参考。


电池储存方式

1. 储存锂电池时请不要充满电，避免长期存储会造成电池活性钝化，自放电速度加快。
2. 请将锂电池存放在温度10°C-30°C之间的室内干燥空间。
3. 需要每隔3个月做一次充放电循环，以保持其活性和恢复性能。




Instructions for 2.4G RC Amphibious Climbing Vehicle

1. Know the remote controller



2. The pairing and battery installation for remote controller




Batteries for remote
2x1.5V "AA" batteries (Not included)

Pairing description of remote control

First turn on the remote controller, at this time the light flashes. Then turn on the car, the controller light is off. It means the pairing is successful.


3. Car battery installation




Attention for charging via USB

1. Battery should be fully charged for the first time using. The battery will still self-discharge when not in use. If not in use for a long time, please ensure that the battery has about half of the power to prevent overdischarge damage. Overcharging can shorten battery life.
2. Please regularly check the cord, plug, casing and other accessories and stop using before being repaired if any damages are found.
3. Do not connect the toys with the power that is not recommended. Charging conditions: Connect the USB smart charging cable with the original battery.
4. Please use appropriate adapter instead of fast charger for charging.
5. Please use the right adapter for charging. Input: 100-240V~50/60Hz 0.2A; output: 5.0V 500mA 0.5-1.5A.
6. Charging notes: To charge the battery, please connect the battery with smart USB charging cable, which has access to power media with USB interface, such as: desktop, laptop, mobile power, USB socket. Alternatively, you can use a USB adapter to connect with the power for charging.
7. Please remove the battery for the remote control truck and the remote controller if they are not expected to use for a long period of time.


4. Play with the remote controller




1. Forward
Press "Forward" button of controller, the car goes forward.



2. Backward
Press "Backward" button of controller, the car goes backward.



3. Turn left
Press "Forward" and "Left turn" buttons at the same time, the car turns left.



4. Turn right
Press "Forward" and "Right turn" buttons at the same time, the car turns right.

*Please read through this manual before operation and keep it properly for future reference.

Battery storage

1. Do not fully charge the battery before keeping it for a long time, otherwise it would result in the passivation, which speeds up the process of self-discharge.
2. Place the battery in dry indoor space with appropriate temperature between 10°C-30°C.
3. Conduct a charge cycle every other 3 months to keep it active and perform well.

